



Maintenance instruction for sealed CROWNBAMBOO® floorings

14 days close season:

Let dry fresh sealing for 24 hours, do not step on it before. The first 14 days only gentle manipulation.

Beginning of maintenance:

For finished parquet you may start with maintenance immediately. For all other fresh sealed flooring start earliest 14 days afterwards with maintenance, the sealed parquet, board and paving floorings are cleaned with a mop, broom or a vacuum cleaner. Slight footstep traces and sticking dirt are removed with a wet good wrung out cloth. Do not cover the flooring with carpets in the first 4 weeks.

More comfortable it's not possible:

Frequency of cleaning and maintenance

- a) Moderate used flooring in flats, according to requirement, approximately every 2 months.
- b) Medium heavily used flooring (staircases, offices, corridors) every 2-4 weeks.
- c) Heavily used floorings as in restaurants, schools or shops every 14 days.
- d) Mostly used places in front of doors, elevators and in corridors possibly maintain more frequently. A gauzily wax film should exist.
- e) Gymnasiums: see separate maintenance instruction.
- f) Apply the maintenance agent very sparingly, 1 litre should be sufficient for 80 sqm.

Cleaning:

During the continuous maintenance cleaning the maintenance agent can be added to the cleaning water with a dosing of 0,3-0,5 litres in 10 litres water. The floor is cleaned and maintained at the same time. A mechanical and manual basic cleaning is only necessary if the flooring has strongly adhering soiling, which cannot be removed by the maintenance cleaning. Suitable for the basic cleaning is our CROWNBAMBOO® basic purifier. Do not flood the flooring with water during the cleaning, because else damages by swelling can occur.

Therefore take up the cleaning solvent liquid immediately. Following maintain with the maintenance agent pure or thinned with 0,3 – 0,5 litre on 10 litres water.

Please pay attention to:

Bamboo is a natural material, which can be affected by the respective temperature of the room and the prevailing air humidity.

One says bamboo is respiring, that means, material and room climatic interactions occur. At relative high moistness of the environment the bamboo flooring takes up moisture and increases its volume.

At relative low moistness of the environment the bamboo flooring releases moisture, so that the volume gets corresponding reduced and joints occur. For bamboo this reaction is markedly lower as for our domestic woods resp. as for us known wooden floorings.

Just a positive speciality of bamboo!

As we have no influence over the level of humidity in your home, the formation of gaps and swelling of the wood are excluded from the guarantee. On hot summer days and during the heating period, the humidity can reach very low levels (without appropriate humidification), which necessarily leads to further drying of the bamboo, thus causing the formation of gaps in your parquet or floorboard. We thus strongly recommend using a humidifier.

- Unfamiliar fresh air
- A lowering of your heating expenses
- Dust, polls and bacteria are nearly completely eliminated.
- Smoke of cigarettes and smells are eliminated.

Important hints:

The protection effect of the sealing can only be retained for heavily used surfaces as in offices, dance halls, and restaurants and similar by timely grinding off and new sealing. The legs of movable furniture have to be protected with matching under layers (e.g. felt pads). At usage of chairs with rollers the use of suitable chair under layers is necessary. Mud flaps resp. clean running zones avoid the intrusion of dirt and therefore are recommended.